




TERMINAL USER GUIDE

Void


GHL MAH DA

Terminal Model: Nexgo N86




Void

Terminal Model: Nexgo N86




STEP
1

Press on < icon to open side menu




STEP
2

Press on **Void**




STEP
3

Key-in Admin Password (Default password 123456) and press **Confirm**



STEP
4

Press on **Card/QR** icon




STEP
5


Select the sale transaction to void

Void


Terminal Model: Nexgo N86



STEP 6 Press **Confirm** to process void



STEP 7 Once void process is successful, merchant receipt will be printed



STEP 8 Press **Yes** to print the customer copy receipt