

SALE (below Rm 250)		SALE (below Rm 250) - continue		SALE (above Rm 250)		SALE (above Rm 250) - continue	
Terminal Display	User- Action	Terminal Display	User- Action	Terminal Display	User- Action	Terminal Display	User- Action
	1. Press the <b>UP Navigation button</b> for <b>Sale</b>		6. Press the <b>UP Navigation button</b> to continue print Customer copy receipt.		1. Press the <b>UP Navigation button</b> for <b>Sale</b>		6. Transaction approved with Merchant copy receipt printed out.
	2. Key-in amount and press <b>&lt;ENTER&gt;</b>				2. Key-in amount and press <b>&lt;ENTER&gt;</b>		7. Press the <b>UP Navigation button</b> to continue print Customer copy receipt.
	3. Ask Card holder to tap the card on terminal screen while green light blinks				3. Ask Card holder to tap the card on terminal screen while green light blinks		
	4. Communicating with host for processing				4. Card holder key in PIN and press <b>&lt;ENTER&gt;</b>		
	5. Transaction approved with Merchant copy receipt printed out.				5. Communicating with host for processing		