



Terminal User Guide

Connectivity Mode

Terminal Model: KD69 Soundbox



Connectivity Mode (GPRS)

Terminal Model: KD69 Soundbox



STEP 1

Press **M (More)** to enter the soundbox menu




STEP 2

Press the **down arrow** to select **Others**



STEP 3

Press **2** to select **Connectivity Mode**



STEP 4

Press **1** to select **GPRS**



STEP 5

Please wait while the soundbox is connecting to the telco sim card

Connectivity Mode (GPRS)

Terminal Model: KD69 Soundbox



STEP
6

Soundbox is
successful
connected

STEP
7

GPRS bar line will
displayed once
successful
connected

Connectivity Mode (WiFi)

Terminal Model: KD69 Soundbox




STEP 1
Press **M (More)** to enter the soundbox menu



STEP 2
Press the **down arrow** to select **Others**



STEP 3
Press **2** to select **Connectivity Mode**




STEP 4
Press **2** to select **WiFi**




STEP 5
When this appears, set up Soundbox WiFi using your phone

Connectivity Mode (WiFi)


Terminal Model: KD69 Soundbox




STEP 6 Go phone's WiFi settings, connect to "Nexgo WiFi" and enter the last 4 digits of the Soundbox serial (At the back)



STEP 7 Choose your preferred WiFi for the Soundbox



STEP 8 Enter the WiFi password and press **Connect**



STEP 9 Soundbox successfully connected to WiFi



STEP 10 **WIFI bar line** will displayed once successful connected