

Version: ALC52070002001

REPRINT LAST RECEIPT

Terminal Display		User- Action
ALLIANCE BANK Sale Void ↓ Settlement	F1 F2 F3 F4	1. Press 3rd purple color button from left
Reprint Last Receipt Any Receipt Last Settlement	F1 F2 F3 F4	2. Select (F2) for Last Receipt
Reprint Last Rcpt Print Cust Copy	Yes No	3. Select (F1) Yes to print customer copy

REPRINT ANY RECEIPT

Terminal Display		User- Action
ALLIANCE BANK Sale Void ↓ Settlement	F1 F2 F3 F4	1. Press 3rd purple color button from left
Reprint Last Receipt Any Receipt Last Settlement	F1 F2 F3 F4	2. Select (F3) for Any Receipt
Reprint Any Rcpt Host: ALC Prev F1 F2 F3 F4 Next Slct Exit		3. Press (F3) to select host ALC or Press (F2) next for other host and Press (F3) to select the host

REPRINT LAST SETTLE

Terminal Display		User- Action
ALLIANCE BANK Sale Void ↓ Settlement	F1 F2 F3 F4	1. Press 3rd purple color button from left
Reprint Last Receipt Any Receipt Last Settlement	F1 F2 F3 F4	2. Select (F4) for Last Settlement

SUMMARY REPORT

Terminal Display		User- Action
ALLIANCE BANK Sale Void ↓ Settlement	F1 F2 F3 F4	1. Press 1st purple color button from right
Reports Summary Report Detail Report Batch History	F1 F2 F3 F4	2. Press (F2) to select Summary Report

DETAIL REPORT

Terminal Display		User- Action
ALLIANCE BANK Sale Void ↓ Settlement	F1 F2 F3 F4	1. Press 1st purple color button from the right
Reports Summary Report Detail Report Batch History	F1 F2 F3 F4	2. Press (F3) to select Detail Report
Detail Report Host: ALC Prev F1 F2 F3 F4 Next Slct Exit		3. Press (F3) to select host ALC or Press (F2) next for other host and Press (F3) to select the host