



Visa/Mastercard, Unionpay, e-Wallet & MyDebit
REPORT & REPRINT Transaction Procedures

Quick Reference Guide
Model: Engage V200t

PRINT REPORT



1. Press <ENTER> key to access main menu

REPRINT LAST RECEIPT



1. Press <ENTER> key to access main menu

REPRINT ANY RECEIPT




1. Press <ENTER> key to access main menu


REPRINT LAST SETTLE REPORT




1. Press <ENTER> key to access main menu




5. Select HOST and press <ENTER>




2. Press navigation key down until 12.REPORT and press <ENTER>




2. Press navigation key down until 11.REPRINT and press <ENTER>




2. Press navigation key down until 11.REPRINT and press <ENTER>




6. Confirm transaction record and press <ENTER>




2. Press navigation key down until 11.REPRINT and press <ENTER>




6. Last Settlement Report printed out




3. Select 1.DETAIL REPORT or 2.SUMMARY REPORT




3. Select 1.LAST RECEIPT and press <ENTER>




3. Select 2.ANY RECEIPT and press <ENTER>




7. Merchant's copy receipt printed out




3. Select 3.LAST SETTLE REPORT and press <ENTER>




4. Press YES to print all report




4. Press YES to print customer receipt



4. Select host to reprint receipt and press <ENTER>



8. Press YES to print customer receipt



4. Press YES to settle all hosts, or Press NO to settle host by host